
Please refer to Assembly and Operating Instructions for further details.



## CAUTION

## PLEASE READ THIS BEFORE USING YOUR LAMP

Follow all instructions closely as detailed in the enclosed "Information and Instruction Booklet".

Never leave the lamp unattended. If you must leave the room, lower the flame.

Always keep out of reach of children.

Keep the lamp away from combustible materials.

Do not place lighted lamp under shelves or close to ceiling. The lamp creates very high air temperatures for approximately 36" above the chimney.

Place the lamp on level, stable surfaces.

Do not place the lamp in a draft.

Use care when removing chimney or gallery when the lamp is lit or has just been extinguished since these parts are very hot.

Those lamps with fabric shades should have the plastic covering removed before lighting.