

READ CAREFULLY**Simplified Directions for Operation of the ALADDIN Kerosene Mantle Lamp**

(Detailed Instructions in Pocket Below)

1. Use clean Kerosene (coal-oil) only.
2. When lighting lamp for first time, be sure wick is soaked no less than 15 minutes.
3. Be sure protective coating is burned off mantle.
4. When lighting wick, remove entire gallery assembly which includes both mantle and chimney. After lighting wick, replace gallery assembly, locking it firmly in position.
5. Turn light up to about three-fourths full glow, otherwise a smoking condition may be brought about. If smoking should occur, turn wick down, and any carbon which may have formed on mantle surface will burn off.
6. Do not use wick cleaner unless carbon crust has formed on wick surface and even then use cleaner lightly to remove only the carbon. Never permit cleaner to scrape or gouge the wick itself as this will roughen the wick surface and reduce efficiency of lamp.
7. When wick is burned short, replace with a new one, as trying to force up a short wick may injure wick-raising mechanism.
8. Do not allow lamp to burn dry, as this will cause wick to burn and char unevenly.
9. To extinguish, turn wick down to low flame and blow, strongly down chimney.
10. In emergency, to use as an open-flame lamp, remove mantle mounting from gallery, and light and operate as a common kerosene lamp.
11. When necessary for crew to leave caboose for any length of time to do switching, etc., be sure to turn lamp down to low-blue flame to prevent smoking.
12. This lamp will provide good service as long as it is operated according to directions. Lamp should be touched only when necessary, because rough handling or playing with lamp is apt to bring about excessive mantle breakage.

ALADDIN INDUSTRIES, INCORPORATED

1485 Merchandise Mart, Chicago, Illinois

TACK
HERETACK
HERE**COMPLETE DIRECTIONS
IN THIS POCKET**